


Select TouchOne or not


ARM

TSXM	R28	OR	LCD_TSXM
TSYM	R29	OR	LCD_TSYM
TSXP	R30	OR	LCD_TSXP
TSYP	R31	OR	LCD_TSYP


G-Sensor



Back Light



1-Wire



Note: If you dont want to use 1-wire, please remove the components in this block, and add the components in top-left block.

LED-	1	LED-	1
LED+	2	LED+	2
GND	3	GND	3
VDD3V3	4	VDD3V3	4
VD16	5	VD16	5
VD17	6	VD17	6
VD18	7	VD18	7
VD19	8	VD19	8
VD20	9	VD20	9
VD21	10	VD21	10
VD22	11	VD22	11
VD23	12	VD23	12
VD8	13	VD8	13
VD9	14	VD9	14
VD10	15	VD10	15
VD11	16	VD11	16
VD12	17	VD12	17
VD13	18	VD13	18
VD14	19	VD14	19
VD15	20	VD15	20
VD0	21	VD0	21
VD1	22	VD1	22
VD2	23	VD2	23
VD3	24	VD3	24
VD4	25	VD4	25
VD5	26	VD5	26
VD6	27	VD6	27
VD7	28	VD7	28
GND	29	GND	29
VCLK	30	VCLK	30
LCD_EN	31	LCD_EN	31
HSYNC	32	HSYNC	32
VS	33	VS	33
VM	34	VM	34
GND	35	GND	35
LCD_TSXP	36	LCD_TSXP	36
LCD_TSYM	37	LCD_TSYM	37
LCD_TSXM	38	LCD_TSXM	38
LCD_TSYP	39	LCD_TSYP	39
Y+	40	Y+	40
Y-	41	Y-	41

LCD-H43i-1124