

转载自: <http://www.fpga4fun.com/>

How the RS-232 serial interface works

<http://www.fpga4fun.com/SerialInterface1.html>

An RS-232 interface has the following characteristics:

- Uses a 9 pins connector "DB-9" (older PCs use 25 pins "DB-25").
- Allows bidirectional full-duplex communication (the PC can send and receive data at the same time).
- Can communicate at a maximum speed of roughly 10KBytes/s.

DB-9 connector

You probably already saw this connector on the back of your PC.



It has 9 pins, but the 3 important ones are:

- pin 2: RxD (receive data).
- pin 3: TxD (transmit data).
- pin 5: GND (ground).

Using just 3 wires, you can send and receive data.

Serial communication

Data is sent one bit at a time; one wire is used for each direction. Since computers usually need at least several bits of data, the data is "serialized" before being sent. Data is commonly sent by chunks of 8 bits. The LSB (data bit 0) is sent first, the MSB (bit 7) last.


Asynchronous communication

This interface uses an "asynchronous" protocol. That means that no clock signal is transmitted along the data. The receiver has to have a way to "time" itself to the incoming data bits.

In the case of RS-232, that's done this way:

- 1 Both side of the cable agree in advance on the communication parameters (speed, format...). That's done manually before communication starts.
- 2 The transmitter sends a "1" when and as long as the line is idle.
- 3 The transmitter sends a "start" (a "0") before each byte transmitted, so that the receiver can figure out that data is coming.
- 4 After the "start", data comes in the agreed speed and format, so the receiver can interpret it.
- 5 The transmitter sends a "stop" (a "1") after each data byte.


Let's see how looks the byte 0x55 when transmitted:



Byte 0x55 is 01010101 in binary.

But since it is transmitted LSB (bit-0) first, the line toggles like that: 1-0-1-0-1-0-1-0.

Here's another example:



Here the data is 0xC4, can you see it?

The bits transitions are harder to see. That illustrates how important it is for the receiver to know at which speed the data is sent.

How fast can we send data?

The speed is specified in baud, i.e. how many bits-per-seconds can be sent. For example, 1000 bauds would mean 1000 bits-per-seconds, or that each bit lasts one millisecond.

Common implementations of the RS-232 interface (like the one used in PCs) don't allow just any speed to be used. If you want to use 123456 bauds, you're out of luck. You have to settle to some "standard" speed. Common values are:

- 1200 bauds.
- 9600 bauds.
- 38400 bauds.
- 115200 bauds (usually the fastest you can go).

At 115200 bauds, each bit lasts $(1/115200) = 8.7\mu\text{s}$. If you transmit 8-bits data, that lasts $8 \times 8.7\mu\text{s} = 69\mu\text{s}$. But each byte requires an extra start and stop bit, so you actually need $10 \times 8.7\mu\text{s} = 87\mu\text{s}$. That translates to a maximum speed of 11.5KBytes per second.

At 115200 bauds, some PCs with buggy chips require a "long" stop bit (1.5 or 2 bits long...) which make the maximum speed drop to around 10.5KBytes per second.

Physical layer

The signals on the wires use a positive/negative voltage scheme.

- "1" is sent using -10V (or between -5V and -15V).
- "0" is sent using +10V (or between 5V and 15V).

So an idle line carries something like -10V.

Baud generator

<http://www.fpga4fun.com/SerialInterface2.html>

Here we want to use the serial link at maximum speed, i.e. 115200 bauds. Other slower speeds would also be easy to generate.

FPGAs usually run at speed well above 115200Hz (RS-232 is pretty slow by today's standards). That means we use a high-speed clock and divide it down to generate a "tick" as close as possible to 115200 times a second.

Synchronous tick from a 1.8432MHz clock

Traditionally, RS-232 chips use a 1.8432MHz clock, because that makes generating the standard baud frequencies very easy. So let's assume we have a 1.8432MHz clock available.

1.8432MHz divided by 16 gives 115200Hz, what a coincidence!

```
reg [3:0] BaudDivCnt;
always @(posedge clk) BaudDivCnt <= BaudDivCnt + 1;

wire BaudTick = (BaudDivCnt==15);
```

So "BaudTick" is asserted once every 16 clocks, i.e. 115200 times a second when using a 1.8432MHz clock.

Synchronous tick from any frequency

The earlier generator was assuming the use of a 1.8432MHz clock. But what do you do if all you have is, say, a 2MHz clock? To generate 115200Hz from a 2MHz clock, you divide the clock by "17.36111111..." Not exactly a round number. The solution is to divide sometimes by 17, sometimes by 18, making sure the ratio stays "17.36111111". That's actually easy to do.

Look at the following "C" code:

```
while(1) // repeat forever
{
    acc += 115200;
    if(acc>=2000000) printf("*"); else printf(" ");

    acc %= 2000000;
}
```

That prints the "*" in the exact ratio, once every "17.36111111..." loops on average.

To obtain the same thing efficiently in an FPGA, we rely on the fact that the serial interface can tolerate a few % of error in the baud frequency generator. It really won't matter if we use "17.3" or "17.4".

FPGA baud generator

It is desirable that the 2000000 be a power of two. Obviously 2000000 is not a power of two. So we change the ratio. Instead of the ratio "2000000/115200", let's use "1024/59" = 17.356. That's very close to our ideal ratio, and makes an efficient FPGA implementation.

```
// 10 bits for the accumulator ([9:0]), and one extra bit for the accumulator carry-out ([10])
reg [10:0] acc; // 11 bits total!

always @(posedge clk)
    acc <= acc[9:0] + 59; // use only 10 bits from the previous result, but save the full 11 bits

wire BaudTick = acc[10]; // so that the 11th bit is the carry-out
```

Using our 2MHz clock, "BaudTick" is asserted 115234 times a second, a 0.03% error from the ideal 115200.

Parameterized FPGA baud generator

The previous design was using a 10 bits accumulator, but as the clock frequency increases, more bits are required.

Here's a design with a 25MHz clock and a 16 bits accumulator. The design is parameterized, so easy to customize.

```
parameter ClkFrequency = 25000000; // 25MHz
parameter Baud = 115200;
parameter BaudGeneratorAccWidth = 16;
parameter BaudGeneratorInc = (Baud<<BaudGeneratorAccWidth)/ClkFrequency;

reg [BaudGeneratorAccWidth:0] BaudGeneratorAcc;
always @(posedge clk)
    BaudGeneratorAcc <= BaudGeneratorAcc[BaudGeneratorAccWidth-1:0] + BaudGeneratorInc;

wire BaudTick = BaudGeneratorAcc[BaudGeneratorAccWidth];
```

One last implementation issue: the "BaudGeneratorInc" calculation is wrong, due to the fact that Verilog uses 32 bits intermediate results, and the calculation exceeds that. Change the line as follow for a workaround.

```
parameter BaudGeneratorInc = ((Baud<<(BaudGeneratorAccWidth-4))+(ClkFrequency>>5))/(ClkFrequency>>4);
```

This line has also the added advantage to round the result instead of truncating.


That's it.

Now that we have a precise enough Baud generator, we can go ahead with the RS-232 transmitter and receiver modules.

RS-232 transmitter module

<http://www.fpga4fun.com/SerialInterface3.html>

We are building an "async transmitter":



It works like that:

- The transmitter takes an 8-bits data, and serializes it (starting when the "TxD_start" signal is asserted).
- The "busy" signal is asserted while a transmission occurs. The "TxD_start" signal is ignored during that time.

The RS-232 parameters used are fixed: 8-bits data, 2 stop bits, no-parity.

Serializing the data

We assume that we have a "BaudTick" signal available, asserted 115200 times a second.

We need to generate the start bit, the 8 data bits, and the stop bits.

A state machine seems appropriate.

```
reg [3:0] state;

always @(posedge clk)
case(state)
  4'b0000: if(TxD_start) state <= 4'b0100;
  4'b0100: if(BaudTick) state <= 4'b1000; // start
  4'b1000: if(BaudTick) state <= 4'b1001; // bit 0
  4'b1001: if(BaudTick) state <= 4'b1010; // bit 1
  4'b1010: if(BaudTick) state <= 4'b1011; // bit 2
  4'b1011: if(BaudTick) state <= 4'b1100; // bit 3
  4'b1100: if(BaudTick) state <= 4'b1101; // bit 4
  4'b1101: if(BaudTick) state <= 4'b1110; // bit 5
  4'b1110: if(BaudTick) state <= 4'b1111; // bit 6
  4'b1111: if(BaudTick) state <= 4'b0001; // bit 7
  4'b0001: if(BaudTick) state <= 4'b0010; // stop1
  4'b0010: if(BaudTick) state <= 4'b0000; // stop2
  default: if(BaudTick) state <= 4'b0000;
endcase
```

Notice how the state machine starts right when "TxD_start" is asserted, but then only advances when "BaudTick" is asserted.

Now, we just need to generate the "TxD" output.

```
reg muxbit;
```

```
always @(state[2:0])
```

```
case(state[2:0])
```

```
  0: muxbit <= TxD_data[0];
```

```
  1: muxbit <= TxD_data[1];
```

```
  2: muxbit <= TxD_data[2];
```

```
  3: muxbit <= TxD_data[3];
```

```
  4: muxbit <= TxD_data[4];
```

```
  5: muxbit <= TxD_data[5];
```

```
  6: muxbit <= TxD_data[6];
```

```
  7: muxbit <= TxD_data[7];
```

```
endcase
```

```
// combine start, data, and stop bits together
```


```
assign TxD = (state<4) | (state[3] & muxbit);
```

That's it! The complete code can be found **[here](#)**.

RS-232 receiver module

<http://www.fpga4fun.com/SerialInterface4.html>

We are building an "async receiver":



Our implementation works like that:

- The module assembles data from the RxD line as it comes.
- As a byte is being received, it appears on the "data" bus. Once a complete byte has been received, "data_ready" is asserted for one clock.

Note that "data" is valid only when "data_ready" is asserted. The rest of the time, don't use it as new data may come that shuffles it.

Oversampling

An asynchronous receiver has to somehow get in-sync with the incoming signal (it doesn't have access to the clock used during transmission).

- To determine when a new data is coming ("start" bit), we oversample the signal at a multiple of the baud rate frequency.
- Once the "start" bit is detected, we sample the line at the known baud rate to acquire the data bits.

Receivers typically oversample the incoming signal at 16 times the baud rate. Here we use 8 times. At 115200 bauds, that gives a sampling rate of 921600Hz.

Let's assume that we have a "Baud8Tick" signal available, asserted 921600 times a second.

The design

First, the incoming "RxD" signal has no relationship with our clock.

We use two D-flipflops to oversample it, and synchronize it to our clock.

```
reg [1:0] RxD_sync;
always @(posedge clk) if(Baud8Tick) RxD_sync <= {RxD_sync[0], RxD};
```

We filter the data, so that short spikes on the RxD line aren't mistaken with start bits.

```
reg [1:0] RxD_cnt;
reg RxD_bit;

always @(posedge clk)
if(Baud8Tick)
begin
```

```

if(RxD_sync[1] && RxD_cnt!=2'b11) RxD_cnt <= RxD_cnt + 1;
else
if(~RxD_sync[1] && RxD_cnt!=2'b00) RxD_cnt <= RxD_cnt - 1;

if(RxD_cnt==2'b00) RxD_bit <= 0;
else
if(RxD_cnt==2'b11) RxD_bit <= 1;
end

```

A state machine allows us to go through each bit received, once a "start" is detected.

```

reg [3:0] state;

always @(posedge clk)
if(Baud8Tick)
case(state)
  4'b0000: if(~RxD_bit) state <= 4'b1000; // start bit found?
  4'b1000: if(next_bit) state <= 4'b1001; // bit 0
  4'b1001: if(next_bit) state <= 4'b1010; // bit 1
  4'b1010: if(next_bit) state <= 4'b1011; // bit 2
  4'b1011: if(next_bit) state <= 4'b1100; // bit 3
  4'b1100: if(next_bit) state <= 4'b1101; // bit 4
  4'b1101: if(next_bit) state <= 4'b1110; // bit 5
  4'b1110: if(next_bit) state <= 4'b1111; // bit 6
  4'b1111: if(next_bit) state <= 4'b0001; // bit 7
  4'b0001: if(next_bit) state <= 4'b0000; // stop bit
  default: state <= 4'b0000;
endcase

```

Notice that we used a "next_bit" signal, to go from bit to bit.

```

reg [2:0] bit_spacing;

always @(posedge clk)
if(state==0)
  bit_spacing <= 0;
else
if(Baud8Tick)
  bit_spacing <= bit_spacing + 1;

wire next_bit = (bit_spacing==7);

```

Finally a shift register collects the data bits as they come.

```

reg [7:0] RxD_data;
always @(posedge clk) if(Baud8Tick && next_bit && state[3]) RxD_data <= {RxD_bit, RxD_data[7:1]};

```

That's it! The complete code can be found **here**.

It has a few improvements; follow the comments in the code.